

## **Polaris Ride Command Power Adapter**

Thank you for purchasing XTC Power Products Power Ride Command Power Adapter for Rear Light Bar, Third Brake Light, Whip Light and License Plate Light.

## For more details on installation go to www.xtcinstall.com

Please read the instructions fully and familiarize yourself with the components before starting the install. Quick Install Guide.

1. Unplug OEM 8-pin light connector located on driver's side rear corner near along the frame tube.



- Plug the adapter into both OEM connectors.
   If you have our TSS Turn Signal System installed, plugging this adapter towards the rear will include the signals, towards the front will only give brake out on the Green and
- 3. Red = Running Lights

Yellow wires.

- 4. Green = Right Turn/Brake Signal
- 5. Yellow = Left Turn/Brake Signal
- 6. Black = Ground

## WARNING! Keep power wire away from any hot or moving parts.

- 7. Run the adapter power wires to License Plate Light, Whip Light and Chase Light Bar.
- 8. Strip 1/4" off the wires and Crimp the Lights wires on following the manufactures directions and the chart above.
- 9. Using a heat gun heat the butt connectors at both ends to seal the connections
- 10. Using the supplied cable tie's, secure the power wire to the car once again making sure that the wire is kept away from any hot or moving parts.

**For more details on installation go to www.xtcinstall.com.** We can also be reached by email at <a href="mailto:support@xtcpowerproducts.com">support@xtcpowerproducts.com</a>

XTC Power Products
A Division of XTC Motorsports LLC
925 N McQueen RD. #101
Gilbert AZ 85233
480-558-8588
www.xtcpowerproducts.com